

# Uplink®

**Uplink®**

iOS App Overview v3.2

*2023 Uplink Security Inc. All rights reserved.*

# LOGIN

Get the Uplink app from the App Store.

Once you've downloaded and installed the app, use the credentials from the quick install manual to log in to your account.

Uplink®

Welcome!

Please Sign In to continue

Username

Password

Forgot your username or password?


Sign In

By signing In you agree with our [Privacy Policy](#).  
All rights reserved by ©2022 Uplink Security Inc..


# FIRST LOOK

Upon first start, the only active functionality will be the events log.

To access the account menu, click here.





Go to settings to configure the App.




# USERNAME AND PASSWORD

Go to the “My Account” icon if you want to change your username and password.



Press “Edit” in the User settings menu.



# USERNAME AND PASSWORD

←

Edit user name

Full Name

demo

Login Name

demo

Save

q w e r t y u i o p

a s d f g h j k l

⬆ z x c v b n m ⬅

123 🎤 space return

Fill in the desired fields and press "Save" when done.

←

Change password

Old password



New password

Confirm password


Save

# LANGUAGE

Go to the “User Settings” menu and select “Language” if you want to change your preferred language.




Select your language of choice and press “Save”.




# NOTIFICATIONS

Go to “Notifications” and choose how you would like to receive different events on your smartphone.



Select the “+ Add” button for your preferred way of notification.






# NOTIFICATIONS


Select type of events to be reported for each notification channel.

Can be used when your phone is in “vibrate” mode and you want to be sure that you won’t miss something.



Your notification channels will be displayed as a list.

To make changes, select the notification you’d like to edit or remove. Thus, returning to the previous screen.







# HOW TO ENABLE REMOTE ARMING/DISARMING

*To enable this functionality, additional wiring and configuration of the alarm panel must be done by your installer.*

Go to "Remote Arming/Disarming" to setup this functionality.




Slide to enable the Remote arming/disarming.




# REMOTE ARMING/DISARMING (KEYBUS WIRING – DSC PANELS)

*To enable this functionality, additional wiring and configuration of the alarm panel must be done by your installer.*

Confirm to enable the functionality.




After confirmation, the Remote Arming/Disarming feature will be available at the homepage.




# REMOTE ARMING/DISARMING (KEYBUS WIRING – HONEYWELL PANELS)

*To enable this functionality, additional wiring and configuration of the alarm panel must be done by your installer.*

Confirm to enable the functionality.




In order to synchronize the settings from the panel ask your alarm installer to enter and exit programming mode from the keypad of your alarm panel.





# REMOTE ARMING/DISARMING (KEYBUS WIRING – HONEYWELL PANELS)

To enable this functionality, additional wiring and configuration of the alarm panel must be done by your installer.

The installer should enter and exit programming mode within the timeframe specified in the mobile app.



Wait for the app to synchronize with your alarm panel.  
*Do not operate the keypad during the sync process.*




# REMOTE ARMING/DISARMING (SYNCH WITH PANEL)

*To enable this functionality, additional wiring and configuration of the alarm panel must be completed by the installer.*

If panel programming is changed after the initial synchronization you need to select "Sync with Panel" and follow the instructions in the app.


***DO NOT operate the keypad during the sync process.***





# REMOTE ARMING/DISARMING (KEYSWITCH WIRING)

To enable this functionality, additional wiring and configuration of the alarm panel must be completed by the installer.

Upon first activation, you will be asked to set the PIN for the remote ARM/DISARM. Enter and confirm your 4-digit PIN then press "Continue"



To complete the initial pairing procedure, you must arm and disarm the alarm panel locally (from the keypad) within 2 minutes.







# REMOTE ARMING/DISARMING (PIN CHANGE)

*To enable this functionality, additional wiring and configuration of the alarm panel must be completed by the installer.*

In case you want to change your PIN, you can change it by selecting "Change the remote PIN".




Enter the old PIN, followed by the new one twice and press "Save" to confirm.






# REMOTE ARMING/DISARMING (PARTITIONS)

*To enable this functionality, additional wiring and configuration of the alarm panel must be completed by the installer.*




Use the slider to quickly "Stay", "Away" or "Disarm" desired partition.




# REMOTE ARMING/DISARMING (ZONES)

To enable this functionality, additional wiring and configuration of the alarm panel must be completed by the installer.

Use the arrow button to see the zones status and bypass a specific zone.




Slide the button to bypass/ unbypass the zone.




# USERS

Go to “Users” menu if you want to add, remove, or edit the users.



Select “Add new user” if you want to add additional user account to this device (e.g., spouse, kids, relatives).



# USERS

Populate the required information in the following fields.

Only “Master user” accounts can add new users, additional devices and label partitions, zones and users.

*\*For security reasons, we recommend that you create only one master user.*

The screenshot shows a mobile application interface for adding a new user. The form is titled 'Add user' and has a back arrow at the top left. The fields are: Full Name, Login Name, Password (with an eye icon), Confirm password (with an eye icon), Email address (with a note: '\* This email will only be used for password recovery.'), Allow remote Arm/Disarm (checkbox), and Master user (checkbox). A red line connects the text 'Populate the required information in the following fields.' to the first five fields. Another red line connects the text 'Only “Master user” accounts can add new users, additional devices and label partitions, zones and users.' to the 'Master user' checkbox. A third red line connects the text 'To allow the remote-control permissions select “Allow remote Arm/Disarm” option.' to the 'Allow remote Arm/Disarm' checkbox. A large red 'Save' button is at the bottom.

Full Name

Login Name

Password

Confirm password

Email address

\* This email will only be used for password recovery.

Allow remote Arm/Disarm


Master user

Save

To allow the remote-control permissions select “Allow remote Arm/Disarm” option.


# LABELS

Navigate to “Labels” menu if you want to name your partitions, zones and users.\*



To label a partition, select “Add Label”.


To label a zone or user use the respective tabs.



*\*To label partitions, zones and users you need to have a “Master User” account*


# LABELS

Select the specific label to edit it.



The 'Labels' screen features a back arrow, a title 'Labels', and three tabs: 'Partitions' (selected), 'Zones', and 'Users'. Under the 'Partitions' tab, there is a list of labels. The first label, 'Area 1' with code '01', is highlighted with a red box. Below it is 'Area 2' with code '02'. At the bottom of the list is a '+ Add Label' button.


Fill in the fields and press "Save" to save the changes.




The 'Edit partition' screen has a back arrow and a title 'Edit partition'. It contains two input fields: 'Code' with the value '01' and 'Label' with the value 'Area 1'. A red box highlights the 'Save' button at the bottom of the form. At the very bottom of the screen, there is a note: 'You can delete permanently this label from here' followed by a red 'Delete' button.

# LABELS (SHORTCUT)

Select the arrow button to edit a specific partition.




Select the "Edit" button to edit the labels of the partition.






# LABELS (SHORTCUT)

Press "Edit labels" to confirm you want to edit them.





Type the changes and press "Done" to save them.




# ADDING MORE DEVICES TO YOUR ACCOUNT

Go to “Add new device” if you want to manage additional devices from the same account.



**For new devices:**  
Enter the serial number of the device that you want to add to this account and the login credentials that comes on the device’s manual.

**For devices that have already been in use:**  
You will have to provide the current username and password.



# HISTORY OF EVENTS

Select “Events” from the main screen to see a list of the events back in time.

*The history of events is kept for 12 months.*

